



Stressless® Saga Low-Back



Stressless® Saga High-Back



Also available with
solid wood frame



84.4"



58.2




75.6"




50.4"



MC
45.3"



129.1"



104"

Stressless® Saga - Measurements (inches)

| Item no. | Model | Width | Height | Depth | Seat Height | Seat Depth |
|-----------------|--------------------------------|-------|--------|-------|-------------|------------|
| 1410020/1432020 | Saga 2 Seat w/ Arms- Low-Back | 66.1 | 35.4 | 33.4 | 18.5 | 21.6 |
| 1410030/1432030 | Saga 3 Seat w/ Arms- Low-Back | 91.3 | 35.4 | 33.4 | 18.5 | 21.6 |
| 1411020/1433020 | Saga 2 Seat w/ Arms- High-Back | 66.1 | 40.1 | 33.4 | 18.5 | 21.6 |
| 1411030/1433030 | Saga 3 Seat w/ Arms- High-Back | 91.3 | 40.1 | 33.4 | 18.5 | 21.6 |

The Stressless® Saga is available in a number of different ways:

- High-Back or Low-Back
- Fully Upholstered or Wood Frame
- Fully Upholstered is available as a sectional, Wood Frame is not.